
	<b>GILES CHEMICAL ~ PREMIER MAGNESIA</b>		
	<b>Company FORM</b>		
	Title: <b>Daily Clean Up for Auto #4</b>	Number: <b>R12-PR-100-F017d</b>	
	Owner: <b>Thomas Evans</b>	Revision: <b>02</b>	
	Effective Date: <b>6/8/18</b>	Page: <b>1 of 1</b>	

## Auto #4 Cleaning Log

Auto lines are cleaned according to the *Repackaging Cleaning Procedure (R13-PR-100-034)*.

Check each block below as the line is being cleaned. Lead Operator must verify that the line is clean before signing. By signing; you are verifying that the line is clean and ready for use. After cleaning is complete turn the sign off sheet in to your supervisor.

Shift #1 <input type="checkbox"/>	Shift #2 <input type="checkbox"/>	Shift #3 <input type="checkbox"/>
-----------------------------------	-----------------------------------	-----------------------------------

### Non-critical Contact Points:

- ☐ Used compressed air to blow off all salt inside and outside of the scales.
- ☐ Emptied each bucket of the scales.
- ☐ Used compressed air to blow salt off the machine from top to bottom.
- ☐ Wiped down the gripper arms, turret and suction cups with a damp rag.
- ☐ Cleaned seal bars and changed seal tape (if needed).
- ☐ Wiped down doors, bottom of machine, discharge belt and pouch magazine feeder with a damp rag.
- ☐ Used compressed air to blow off the long conveyor and then wiped it down with a damp rag.
- ☐ Used compressed air to blow off the taper, wiped it down with a damp rag and changed the tape roll (if needed).
- ☐ Cleaned up all nonconforming pouches and disposed of salt following the *Rework and Reprocessing of Salt* procedure (*R12-PR-100-007*).
- ☐ Swept the area around the machine to clean up all debris.
- ☐ Ensure Walking Finger Arm, cup filler, scale (above and below the buckets), and zipper opener bolts/springs are in place

### Critical Contact Points:

- ☐ Removed fill funnel and washed with diluted Dawn detergent, rinsed with hot water and sprayed with Isopropyl alcohol.
- ☐ Cleaned storage container with diluted Dawn detergent, rinsed with hot water and sprayed with Isopropyl alcohol.
- ☐ Put funnel into clean storage container.
- ☐ Blew out Hopper with compressed air and sprayed it with Isopropyl alcohol while it was empty.
- ☐ Posted correct ID sign (RED-Not Clean, GREEN-Cleaned for USP, and BLUE-Cleaned for Tech Grade) stating the condition of the machine.

Comments:

Operator Signature: \_\_\_\_\_ Date: \_\_\_\_\_

- ☐ I hereby verify that this line is clean, has the correct ID sign posted and is ready for use

Supervisor Signature: \_\_\_\_\_ Date: \_\_\_\_\_

Reviewed By: QA Initials: \_\_\_\_\_ Date: \_\_\_\_\_

### Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for accuracy of the document.