
	GILES CHEMICAL ~ PREMIER MAGNESIA		
	Company Procedure		
	Title: PM Shrink wrapper(s)	Number: M13-PR-200-030	
	Owner: Randy Lanning	Revision: 0	
	Effective Date: 05/30/2013	Page: 1 of 2	

1.0 Purpose

This procedure establishes the requirements for the weekly preventive maintenance of the shrink wrappers at the Repackaging facility.

2.0 Scope

This procedure applies to the shrink wrappers at the Repackaging facility. This procedure shall be performed weekly.

3.0 Responsibility

Maintenance will lead PM of machines with assistance of assigned production employees.

4.0 Safety Considerations

All Contractors/Service Personnel are expected to observe all safety rules and regulations while on Giles Chemical property.

Safety is a condition of employment. Employees are not authorized to work in an unsafe manner and are prohibited from harming the environment of the facility or community.

5.0 Materials/Equipment



- Tools necessary for PM of shrink wrappers

6.0 Procedure

1. Turn off power supply and unplug from receptacle on wall
2. Remove turn table 4-3/8" bolts from top and then screw 1/2" lifting eye into center of the table, take choker and shackle and using lifting eye remove with fork truck.
3. Check chain for proper lubrication and tension
4. Grease guide wheels (qt=4) with red grease
5. Check and clean photo eye switch
6. After completion of servicing; reverse sequence and re-install table

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.

	GILES CHEMICAL ~ PREMIER MAGNESIA		
	Company Procedure		
	Title: PM Shrink wrapper(s)	Number: M13-PR-200-030	
	Owner: Randy Lanning	Revision: 0	
	Effective Date: 05/30/2013	Page: 2 of 2	

7.0 Reference Documents

PM Shrink Wrapper(s) form (M13-PR-200-F030)

8.0 Change Information

New Document

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.