
	GILES CHEMICAL ~ PREMIER MAGNESIA		
	Company Form		
	Title: PM Shrink Wrapper	Number: M13-FM-200-005	
	Owner: Randy Lanning	Revision: 0	
	Effective Date: 05/30/2013	Page: 1 of 1	

	Turn off power supply and unplug from receptacle on wall
	Remove turn table 4-3/8" bolts from top and then screw 1/2" lifting eye into center of the table, take choker and shackle and using lifting eye remove from fork truck.
	Check chain for proper lubrication and tension
	Grease guide wheels (qt=4) with red grease
	Check and clean photo eye switch
	After completion of servicing; reverse sequence and re-install table

Maintenance Signature: _____ Date: _____

Production Supervisor: _____ Date: _____

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for accuracy of the document