

**GILES CHEMICAL ~ PREMIER MAGNESIA****Company FORM**Title: **Daily Clean Up for Auto #2**Number: **R12-PR-100-F017b**Owner: **Thomas Evans**Revision: **03**Effective Date: **5/1/17**Page: **1 of 1**

Auto #2 Cleaning Log

Auto lines are cleaned according to the ***Repackaging Cleaning Procedure (R13-PR-100-034)***.

Check each block below as the line is being cleaned. Lead Operator must verify that the line is clean before signing. By signing; you are verifying that the line is clean and ready for use. After cleaning is complete turn the sign off sheet in to your supervisor.

Shift #1 <input type="checkbox"/>	Shift #2 <input type="checkbox"/>	Shift #3 <input type="checkbox"/>
-----------------------------------	-----------------------------------	-----------------------------------

Non-critical Contact Points:

- ☐ Used compressed air to blow off all salt from the top of the machine starting at the top of the AMS.
- ☐ Used compressed air to blow out the cup area and the area where the chain is located.
- ☐ Used compressed air to blow salt off the machine from top to bottom.
- ☐ Wiped down the gripper arms, turret and suction cups with a damp rag.
- ☐ Cleaned seal bars and changed seal tape (if needed).
- ☐ Wiped down doors, bottom of machine, discharge belt and pouch magazine feeder with a damp rag.
- ☐ Used compressed air to blow off the Alpha Weigh Checker.
- ☐ Used compressed air to blow off the long conveyor and then wiped it down with a damp rag.
- ☐ Used compressed air to blow off the taper, wiped it down with a damp rag and changed the tape roll (if needed).
- ☐ Cleaned up all nonconforming pouches and disposed of salt following the *Rework and Reprocessing of Salt* procedure (R12-PR-100-007).
- ☐ Swept the area around the machine to clean up all debris.
- ☐ Ensure Walking Finger Arm, gas flush, and cup filler, and zipper opener bolts/springs are in place

Critical Contact Points:

- ☐ Removed fill funnel, small auger and collar. Washed each with diluted Dawn detergent, rinsed with hot water and sprayed with Isopropyl alcohol.
- ☐ Cleaned storage container with diluted Dawn detergent, rinsed with hot water and sprayed with Isopropyl alcohol.
- ☐ Put funnel into clean storage container.
- ☐ Blew out Hopper #1 with compressed air and sprayed it with Isopropyl alcohol while it was empty.
- ☐ Posted correct ID sign (RED-Not Clean, GREEN-Cleaned for USP, and BLUE-Cleaned for Tech Grade) stating the condition of the machine.

Comments:

Operator Signature: _____ Date: _____

- ☐ I hereby verify that this line is clean, has the correct ID sign posted and is ready for use

Supervisor Signature: _____ Date: _____

Reviewed By: QA Initials: _____ Date: _____

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for accuracy of the document.