	GILES CHEMICAL		
	COMPANY PROCEDURE		
	Evaluating Suspended Solids	Page : 1 of 3	Revision : 02 Date : 6/5/2009
	Author: Patrick Owen	Job Specific	

Personnel responsible:

1. Lead Operator

Safety:


Safety Glasses and Safety Shoes

Summary:

Pull sample of slurry from Vacuum Crystallizer discharge pump and estimate the suspended solids using a graduated cylinder.

Procedure:

1. Pull sample from feed line to centrifuge:
 - a) Start with a clean 250mL graduated cylinder,
 - b) Open the sample valve and close the feed valve so full flow from Vacuum Crystallizer is going through the sample line.
 - c) Let the sample line run for **at least** 5 full seconds before getting the sample.
 - d) Obtain a sample by placing the graduated cylinder in the drain pot under the flow from the sample line.
 - e) Completely fill the graduated cylinder.
 - f) Open the feed valve and close the sample valve.
 - g) Wash off the outside of the graduated cylinder in the sink.
2. Evaluate sample:
 - a) Set the graduated cylinder on a solid surface and allow at least 2 minutes for the solids to settle.
 - b) The dividing line between the liquid and solids will appear.
 - c) Report the solids as the mL level of the dividing line to the nearest 10 mL.(example: 120, 130, etc)

	GILES CHEMICAL		
	COMPANY PROCEDURE		
	Evaluating Suspended Solids	Page : 2 of 3	Revision : 02 Date : 6/5/2009
	Author: Patrick Owen	Job Specific	

TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				



**GILES CHEMICAL
COMPANY PROCEDURE**

Evaluating Suspended Solids

Page : 3 of 3

Revision : 02
Date : 6/5/2009

Author: **Patrick Owen**

Job Specific

Revision Number	Revision Date	Revision Author	Revision Description
00	9/9/2005	PLO	Original document
01	12/15/2006	PLO	Updated after operator training
02	6/5/2009	PLO	Updated format and reviewed