

GILES CHEMICAL CORPORATION		
COMPANY PROCEDURE		
Standard Operating Procedure	Page : 1 of 2	Revision : Date : 02/12/07
Author: Maintenance	Title: Lock Out Tag Out #1 Centrifuge	

**Safety:** *All safety glasses and appropriate safety apparel is to be worn at all times.*

**Purpose or Objective:** *The purpose of this procedure is to define the process required to lock out the Centrifuge #1 at the main facility at 102 Commerce Street*

**Procedure:** *The proper process to lockout Centrifuge #1 is as follows:*

- 1. Notify all affected employees that the machine is being taken out of production.*
- 2. Locate disconnect for Centrifuge #1*
- 3. Turn disconnect for Centrifuge #1 to the off position*
- 4. Install multi-locking device on the disconnect*
- 5. ID tag with name, date and time*
- 6. Test start switch to ensure equipment is not operational*

*Proper procedure to return equipment to operation:*

- 1. Make sure all work is complete and all tools and maintenance equipment has been removed from the machine.*
- 2. Notify all affected employees that equipment is about to be put back into service.*
- 3. Remove Id tag with name, date and time*
- 4. Remove padlock-multi locking device from disconnect for starter*
- 5. Turn disconnect handle to the on position*
- 6. Ensure that Dust Collector starter for the #2Dryer is operating properly and available to be returned to production*

<b>GILES CHEMICAL CORPORATION</b>			
<b>COMPANY PROCEDURE</b>			
<b>Standard Operating Procedure</b>		Page : 2 of 2	Revision : Date : 02/12/07
	Author: Maintenance Title: Lock Out Tag Out #1 Centrifuge		

**TRAINING DOCUMENTATION**

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				