

GILES CHEMICAL							
COMPANY PROCEDURE							
Bagger Operation		Page :	1 of 3	Revision Date	:	02 05/27/09	
Author: Selwyn Scoggin		Job Spe	ecific	Date	•	03/21/09	

Personnel responsible:

Lead Operator and / or Salt Operator

Safety equipment:

All safety glasses and appropriate safety apparel is to be worn at all times.

Summary:

This procedure covers operation of the Bagging machine. The bagger takes the preprinted film, folds it, seals it, fills it, and discharges the filled bag onto a conveyor.

Procedure:

- 1. Starting Bagger
 - a. Turn on power to bagger (if not already on)
 - b. Press "MK on" button on touch screen. (Machine will not turn on unless all doors are closed).
 - c. Allow machine to "warm up".
 - d. Calibrate scales
 - e. Load film.
 - f. Close doors
 - g. Press "start auto" button on screen
 - h. Press "start with product" button on screen.

2. Bagger Operation

- a. Operator to check bag weights every hour.
- b. Calibrate scales at beginning of shift.
- c. Change film when needed.
- d. Periodically check for leaking bags and bad seals.
- e. Listen for hopper hi level alarm.
- f. Make necessary interventions, or call maintenance for help.

3. Stopping Bagger

- a. Shut off feed to hopper
- b. Run bagger until empty
- c. Press "pause" button on touch screen.
- d. Press "one empty bag" button on touch screen.
- e. Press "stop auto" button on touch screen.

4. Loading film.

- a. Open rear doors
- b. Push back keepers on both sides of rolls where bobbins attach to frame.
- c. Lower film bars onto table and cut film along slanted line.
- d. Use cart to lift roll from frame, and move to storage rack.
- e. Use cart to guide new roll into place.
- f. Lower film onto bobbin support arms and latch.
- g. Bring film up across idler roller, align print, cut, and tape to old film still in machine.
- h. Close doors, reset any alarms, and run empty bags until taped seam comes through.
- i. Continue to run empty bags until Eye Mark is fully aligned.
- j. Press "start auto" button on touch screen.
- k. Press "run with product" button on touch screen.



GILES CHEMICAL						
COMPANY PROCEDURE						
Bagger Operation		Dage ·	2 of 3	Revision	:	02
		rage .		Date	:	05/27/09
Author: Selwyn Scoggin		Job Sp	ecific			

TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				



GILES CHEMICAL COMPANY PROCEDURE

Bagger Operation Page : 3 of 3

Revision : 02 Date : 05/27/09

Author: Selwyn Scoggin Job Specific

Revision Number	Revision Date	Revision Author	Revision Description
00	10/11/05	SS	New Document
01	06/05/08	РО	Added Conveyor in place of Computer in summary. Added "Continue to run empty bags until eye mark is fully aligned. Removed document number, Changed Header
02	05/27/09	JВ	Updated to new Company Format