
	GILES CHEMICAL ~ PREMIER MAGNESIA		
	Company Form		
	Title: PM Shrink Wrapper	Number: M13-PR-200-F030	
	Owner: Lee Cagle	Revision: 01	
	Effective Date: 08/12/2014	Page: 1 of 1	

For each of the items listed below please place a check in the **Completed** column as you complete that task. For any item that is not completed please place a check in the **Not Completed** column and give a brief explanation in the **Notes** section as to why it wasn't completed.

Items to be completed	Completed	Not Completed
Shrink Wrapper <div style="float: right;"> Machine #: Asset Tag #: </div>		
Turn off power supply and unplug from receptacle on wall		
Remove turn table 4-3/8" bolts from top and then screw 1/2" lifting eye into center of the table, take choker and shackle and using lifting eye remove from fork truck.		
Check chain for proper lubrication and tension		
Grease guide wheels (qt=4) with red grease		
Check and clean photo eye switch		
After completion of servicing; reverse sequence and re-install table		
Notes:		

Maintenance Signature: _____ Date: _____

Maintenance Supervisor: _____ Date: _____

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for accuracy of the document