
	<b>GILES CHEMICAL ~ PREMIER MAGNESIA</b>		
	<b>Company Procedure</b>		
	Title: <b>Hydrometer and Specific Gravity Readings for Liquid Loads</b>	Number: <b>L13-PR-100-048</b>	
	Owner: <b>Lee Cagle</b>	Revision: <b>01</b>	
	Effective Date: <b>07/02/13</b>	Page: <b>1 of 2</b>	

## 1.0 Purpose

The purpose of this procedure is to explain the proper steps for testing liquid loads.

## 2.0 Scope

This procedure applies to all liquid loads shipped from the Manufacturing and Greendale facilities.

## 3.0 Responsibility

Material Handler: Responsible for hydrometer readings.

QA Lab: Responsible for specific gravity readings.

## 4.0 Safety Considerations

Wear appropriate PPE for the area you're working in.

Safety is a condition of employment. Employees are not authorized to work in an unsafe manner and are prohibited from harming the environment of the facility or community.

## 5.0 Materials/Equipment

- 250 ml Sample Bottle
- 250 ml Graduated Cylinder
- Hydrometer
- pH Meter
- % MgSO<sub>4</sub> Chart
- 500 ml Beaker
- Balance
- 25 ml Volumetric Flask



## 6.0 Procedure

### Sampling:

1. Obtain a clean 250 ml sample bottle.
2. Using the sampling device, pull a sample from the finished liquid load.
3. Place sample in sample bottle and transfer sample to testing area.

### Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for accuracy of the document

	<b>GILES CHEMICAL ~ PREMIER MAGNESIA</b>		
	<b>Company Procedure</b>		
	Title: <b>Hydrometer and Specific Gravity Readings for Liquid Loads</b>	Number: <b>L13-PR-100-048</b>	
	Owner: <b>Lee Cagle</b>	Revision: <b>01</b>	
	Effective Date: <b>07/02/13</b>	Page: <b>2 of 2</b>	

### Hydrometer Reading:

1. Obtain a *Hydrometer and Specific Gravity Worksheet (L13-PR-100-F048)* and record the following data.
2. Place pH probe into sample and record the pH and temperature.
3. Pour sample into a 250 ml graduated cylinder.
4. Place Hydrometer into sample and record the reading.
5. Using the % MgSO<sub>4</sub> chart, record the percent the load shipped as.

### Specific Gravity Reading:

Follow the *Steps for Liquid Load Testing* procedure (*L12-PR-100-024*)  
Record data on the *Hydrometer and Specific Gravity Worksheet (L13-PR-100-F048)*.

## 7.0 Reference Documents

<i>Hydrometer and Specific Gravity Worksheet</i>	<i>(L13-PR-100-F048)</i>
<i>Steps for Liquid Load Testing</i>	<i>(L12-PR-100-024)</i>
<i>% MgSO<sub>4</sub> Chart</i>	<i>(L12-FM-100-F033)</i>

## 8.0 Change Information

New Document

### Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for accuracy of the document