


|   |  |               |  |
|---|--|---------------|--|
|  | <b>GILES CHEMICAL</b>                      |               |  |
|   | <b>COMPANY POLICY / PROCEDURE</b>          |               |  |
|   | <b>Filling and Starting a Crystallizer</b> | Page : 1 of 3 | Revision : 09/30/2008<br>Date : 12/15/2008 |
|   | Author: <b>Patrick Owen</b>                | Job Specific  |  |

**Personnel responsible:**

1. Lead Operator, Material Handler

**Safety:**

Safety shoes and safety glasses are required when working in, on, or around the crystallizers.

**Summary:**

To start a crystallizer, it is emptied of any water, filled from the bottom, and slowly brought to operating condition for production.

**Procedure:**

**A. Fill the Crystallizer**

1. Drain the elbow with the elbow drain and close it.
2. Open the bottom valve on the crystallizer to ensure it has been drained.
3. Connect a hose from the Brine Tank #2 discharge valve to the Liquid Load Pump.
4. Connect the outlet of the Liquid Load Pump to the bottom of the crystallizer.
5. Open the Brine Tank #2 discharge valve and start the Liquid Load Pump.
6. Begin filling the crystallizer with brine.
7. When the level goes above the elbow, (about 120 inches) start the elbow pump (#1-47Hz, #2-43Hz, #3-60Hz)
8. When the liquid reaches the proper level, close the bottom valve.
9. Stop the Liquid Load Pump and close the Brine Tank #2 discharge valve.
10. Uncouple the hoses and clean up.
11. Using the Mother Liquor feed, fill the Crystallizer up to 165 inches.

**B. Start the Crystallizer**

1. Ensure the small condenser pump is running.
2. Start the large condenser water pump and the mass flow pump.
3. Start the vacuum pump, open the valve at the small condenser to begin water flow, and turn on the steam to the steam ejector.
4. The temperature will begin to drop. When it gets to 30 deg C., (temperature reading from mass flow meter and/or production screen) crystals will appear in the sight glass. The crystallizer is now ready for production.
5. Adjust the elbow pump (53 Hz on #1, 47 Hz on #2, 60 Hz on #3) as crystal size develops.
6. Begin feeding brine at 15 gpm into the heat exchanger and back to the Mother Liquor Tank (see the Remelt Heat Exchanger procedure)
7. Start the discharge pump to the centrifuge at about 15 gpm to begin with because the crystals will be fine. After 8 to 12 hours the crystals will grow enough to increase the discharge rate as required for production needs.
8. Very important that all lines used in starting crystallization production be cleaned to prevent salt buildup.



**GILES CHEMICAL**  
**COMPANY POLICY / PROCEDURE**

**Filling and Starting a Crystallizer**

Page : 2 of 3

Revision : 09/30/2008  
Date : 12/15/2008

Author: **Patrick Owen**

Job Specific

**TRAINING DOCUMENTATION**

|    | EMPLOYEE | TITLE | SIGNATURE | DATE |
|----|----------|-------|-----------|------|
| 1  |          |       |           |      |
| 2  |          |       |           |      |
| 3  |          |       |           |      |
| 4  |          |       |           |      |
| 5  |          |       |           |      |
| 6  |          |       |           |      |
| 7  |          |       |           |      |
| 8  |          |       |           |      |
| 9  |          |       |           |      |
| 10 |          |       |           |      |
| 11 |          |       |           |      |
| 12 |          |       |           |      |
| 13 |          |       |           |      |
| 14 |          |       |           |      |
| 15 |          |       |           |      |
| 16 |          |       |           |      |
| 17 |          |       |           |      |
| 18 |          |       |           |      |



**GILES CHEMICAL**  
**COMPANY POLICY / PROCEDURE**

**Filling and Starting a Crystallizer**

Page : 3 of 3

Revision : 09/30/2008  
Date : 12/15/2008

Author: **Patrick Owen**

Job Specific

| Revision Number | Revision Date | Revision Author | Revision Description                         |
|-----------------|---------------|-----------------|--|
| 00              | 12/5/2005     | PO              | Original Procedure                           |
| 01              | 12/7/2007     | N/A             | Changes not documented                       |
| 02              | 9/30/2008     | PO              | Updated for using brine to fill crystallizer |
|                 |               |                 |  |
|                 |               |                 |  |
|                 |               |                 |  |
|                 |               |                 |  |