

GILES CHEMICAL CORPORATION		
COMPANY PROCEDURE		
Standard Operating Procedure	Page : 1 of 3	Revision : 12/15/2002 Date : 9/9/2005
Author: Patrick Owen	Title: (00) Evaluating Suspended Solids	

Manuf-Crys-04

Personnel responsible:

1. Lead Operator

Safety:

Safety Glasses and Safety Shoes

Summary:

Pull sample of slurry from Vacuum Crystallizer discharge pump and estimate the suspended solids using a graduated cylinder.

Procedure:

1. Pull sample from feed line to centrifuge:
 - a) Start with a clean 250mL graduated cylinder,
 - b) Open the sample valve and close the feed valve so full flow from Vacuum Crystallizer is going through the sample line.
 - c) Let the sample line run for **at least** 5 full seconds before getting the sample.
 - d) Obtain a sample by placing the graduated cylinder in the drain pot under the flow from the sample line.
 - e) Completely fill the graduated cylinder.
 - f) Open the feed valve and close the sample valve.
 - g) Wash off the outside of the graduated cylinder in the sink.
2. Evaluate sample:
 - a) Set the graduated cylinder on a solid surface and allow at least 2 minutes for the solids to settle.
 - b) The dividing line between the liquid and solids will appear.
 - c) Report the solids as the mL level of the dividing line to the nearest 10 mL.(example: 120, 130, etc)

GILES CHEMICAL CORPORATION		
COMPANY PROCEDURE		
Standard Operating Procedure	Page : 2 of 3	Revision : 12/15/2002 Date : 9/9/2005
Author: Patrick Owen	Title: (00) Evaluating Suspended Solids	

Manuf-Crys-04

REVISION HISTORY

<u>Revision Date</u>	<u>Revision Number</u>	<u>Revision Description</u>
9/28/05	00	New Document
12/15/06	01	Update from Operator training

GILES CHEMICAL CORPORATION			
COMPANY PROCEDURE			
Standard Operating Procedure		Page : 3 of 3	Revision : 12/15/2002 Date : 9/9/2005
Author:	Patrick Owen Title: (00) Evaluating Suspended Solids		

Manuf-Crys-04

TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				