



GILES CHEMICAL ~ PREMIER MAGNESIA

Company Procedure

Title: **Swab Test Manual Lines**

Number: **R12-PR-100-F015b**

Owner: **Charles Huggins**

Revision: **06**

Effective Date: **10/06/2017**

Page: **1 of 1**



Swab Test Manual Line

Swab tests are to be performed any time a line is being switched from scented salt production to unscented production. When performing a swab test follow *Residual Fragrance Test using TLC (R12-PR-100-015)*.

- Label a zip lock bag for each of the following 4 points to be swabbed.
- Wearing latex gloves roll each end of the swab on the station being swabbed, place in the zip lock bag labeled for that station and close seal.
- Submit swabs to the Quality Unit for testing and wait for results before starting production on the line being tested.

☐ Manual Line #1

- | | |
|----------------------------|--------------------------|
| 1. Fill Table | <input type="checkbox"/> |
| 2. Funnel | <input type="checkbox"/> |
| 3. Product Conveyor/Sealer | <input type="checkbox"/> |
| 4. Metal Detector | <input type="checkbox"/> |
| 5. Packing Table | <input type="checkbox"/> |

Start Date: _____ End Date: _____

Cleaned By: _____ Date: _____

Tested By: _____ Date: _____

Results: **Pass / Fail**

Reviewed By: _____ Date: _____

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for accuracy of the document.