
	GILES CHEMICAL ~ PREMIER MAGNESIA	
	Company Procedure	
	Title: LOTO #2 Dryer Dust Collector Starter	Number: S12-PR-200-024
	Owner: Robert Willis	Revision: 01
	Effective Date: 05/21/13	Page: 1 of 2



1.0 Purpose

The purpose of this procedure is to define the process required to lock out the Dryer #2 Dust Collector Starter at the Manu8facturing facility.

2.0 Scope

This procedure applies to all maintenance workers.

3.0 Responsibility

Maintenance and Production

4.0 Safety Considerations

Safety glasses and appropriate safety apparel is to be worn at all times

Safety is a condition of employment. Employees are not authorized to work in an unsafe manner and are prohibited from harming the environment of the facility or community.

5.0 Materials/Equipment

- Lock
- Tag
- Lock out device

6.0 Procedure

The proper process to lockout Dryer #2 Dust Collector Starter is as follows:


1. Notify all affected employees that the machine is being taken out of production.
2. Locate disconnect for Dryer #2 Dust Collector Starter
3. Turn disconnect for Dryer #2 Dust Collector Starter to the off position
4. Install multi-locking device on the disconnect
5. ID tag with name, date and time
6. Test start switch to ensure starter is not operational


Proper procedure to return equipment to operation:

1. Make sure all work is complete and all tools and maintenance equipment has been removed from the machine.
2. Notify all affected employees that equipment is about to be put back into service.

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.

	GILES CHEMICAL ~ PREMIER MAGNESIA	
	Company Procedure	
	Title: LOTO #2 Dryer Dust Collector Starter	Number: S12-PR-200-024
	Owner: Robert Willis	Revision: 01
	Effective Date: 05/21/13	Page: 2 of 2



3. Remove Id tag with name, date and time
4. Remove padlock-multi locking device from disconnect for starter
5. Turn disconnect handle to the on position
6. Ensure that Dust Collector starter for the #2Dryer is operating properly and available to be returned to production

7.0 Reference Documents

N/A

8.0 Change Information

Document review- updated format using new template and numbering system.

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.