
	GILES CHEMICAL ~ PREMIER MAGNESIA		
	Company Procedure		
	Title: Hydrometer and Specific Gravity Readings for Liquid Loads	Number: L13-PR-100-048	
	Owner: Hunter Douglas	Revision: 02	
	Effective Date: 05/25/16	Page: 1 of 2	

1.0 Purpose

The purpose of this procedure is to explain the proper steps for testing liquid loads.

2.0 Scope

This procedure applies to all liquid loads shipped from the Manufacturing and Greendale facilities.

3.0 Responsibility

Material Handler: Responsible for hydrometer readings.

QA Lab: Responsible for specific gravity readings.

4.0 Safety Considerations

Wear appropriate PPE for the area you're working in.

Safety is a condition of employment. Employees are not authorized to work in an unsafe manner and are prohibited from harming the environment of the facility or community.

5.0 Materials/Equipment

- 250 ml Sample Bottle
- 250 ml Graduated Cylinder
- Hydrometer
- pH Meter
- % MgSO₄ Chart
- 500 ml Beaker
- Balance
- 25 ml Volumetric Flask



6.0 Procedure

Sampling:

1. Obtain a clean 250 ml sample bottle.
2. Using the sampling device, pull a sample from the finished liquid load.
3. Place sample in sample bottle and transfer sample to testing area.

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for accuracy of the document

	GILES CHEMICAL ~ PREMIER MAGNESIA		
	Company Procedure		
	Title: Hydrometer and Specific Gravity Readings for Liquid Loads	Number: L13-PR-100-048	
	Owner: Hunter Douglas	Revision: 02	
	Effective Date: 05/25/16	Page: 2 of 2	

Hydrometer Reading:

1. Obtain a *Hydrometer and Specific Gravity Worksheet (L13-PR-100-F048)* and record the following data.
2. Place pH probe into sample and record the pH and temperature.
3. Pour sample into a 250 ml graduated cylinder.
4. Place Hydrometer into sample and record the reading.
5. Using the % MgSO₄ chart, record the percent the load shipped as.

Specific Gravity Reading:

Follow the *Steps for Liquid Load Testing* procedure (*L12-PR-100-024*)
Record data on the *Hydrometer and Specific Gravity Worksheet (L13-PR-100-F048)*.

7.0 Reference Documents

<i>Hydrometer and Specific Gravity Worksheet</i>	<i>(L13-PR-100-F048)</i>
<i>Steps for Liquid Load Testing</i>	<i>(L12-PR-100-024)</i>
<i>% MgSO₄ Chart</i>	<i>(L12-FM-100-F033)</i>

8.0 Change Information

New Document

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for accuracy of the document