
	<b>GILES CHEMICAL ~ PREMIER MAGNESIA</b>		
	<b>Company Procedure</b>		
	Title: <b>Mass Flow Density Loop Washout</b>	Number: <b>P12-PR-200-027</b>	
	Owner: <b>Robert Willis/Lester Parton</b>	Revision: <b>2</b>	
	Effective Date: <b>05/13/13</b>	Page: <b>1 of 7</b>	

## 1.0 Purpose

To outline steps to clean out the Mass Flow Density Loops on Crystallizers #1, #2, and #3

## 2.0 Scope

This procedure applies to all manufacturing workers.

## 3.0 Responsibility

All

## 4.0 Safety Considerations

**All safety glasses and appropriate safety apparel is to be worn at all times. This includes wearing the appropriate protection for working at heights above six feet and using the appropriate lockout devices for production equipment.**

Safety is a condition of employment. Employees are not authorized to work in an unsafe manner and are prohibited from harming the environment of the facility or community.

## 5.0 Materials/Equipment

N/A

## 6.0 Procedure

These procedures should be conducted on the Density Loops every two hours to ensure proper operation on the Loops

### Crystallizer #2 and Crystallizer #3

1. Quick connect the water connection to the density washout valve if not connected. Turn off Input valve on Density Loop going into crystallizer. Turn on Density Washout valve to wash water into the system.

### Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.



## GILES CHEMICAL ~ PREMIER MAGNESIA

### Company Procedure

Title: **Mass Flow Density Loop Washout**

Number: **P12-PR-200-027**

Owner: **Robert Willis/Lester Parton**

Revision: **2**

Effective Date: **05/13/13**

Page: **2 of 7**

**PREMIER**  
MAGNESIA,  
LLC



2. Next ensure that density loop return valve is on. Make sure sample port is in the off position. Once washout of this portion is begun open sample port valve to full open position to ensure that line is washed out properly. Then return sample port valve to the off position.





3. While washing back into density loop return valve check Density on Flow meter to ensure that the density is close to 1.0.



### Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.

	<b>GILES CHEMICAL ~ PREMIER MAGNESIA</b>		
	<b>Company Procedure</b>		
	Title: <b>Mass Flow Density Loop Washout</b>	Number: <b>P12-PR-200-027</b>	
	Owner: <b>Robert Willis/Lester Parton</b>	Revision: <b>2</b>	
	Effective Date: <b>05/13/13</b>	Page: <b>3 of 7</b>	

4. Next turn Density Loop Return Valve to the off position and turn Density Loop Pump off using the start/stop button located between density loop for #2 and #3 Crystallizers.



5. Return Input valve to the open position to wash back into the crystallizer.



6. Next turn pump on using the start/stop button. Turn Density loop return valve to the open position and then at the same time cut the Input valve on going into the crystallizer and cut off the Density Washout valve to ensure pump will be working properly.

### Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.



## GILES CHEMICAL ~ PREMIER MAGNESIA

### Company Procedure

Title: **Mass Flow Density Loop Washout**

Number: **P12-PR-200-027**

Owner: **Robert Willis/Lester Parton**

Revision: **2**

Effective Date: **05/13/13**

Page: **4 of 7**



### Crystallizer #1

1. Turn off Input valve going into crystallizer #1 and at the same time cut on Density washout valve to ensure wash water into the system.



2. Next ensure that density loop return valve is on. Make sure sample port is in the off position. Once washout of this portion is begun open sample port valve fully open to ensure that line is washed out properly. Then return sample port valve to the off position.

### Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.





## GILES CHEMICAL ~ PREMIER MAGNESIA

### Company Procedure

Title: **Mass Flow Density Loop Washout**

Number: **P12-PR-200-027**

Owner: **Robert Willis/Lester Parton**

Revision: **2**

Effective Date: **05/13/13**

Page: **5 of 7**

**PREMIER**  
MAGNESIA,  
LLC



3. While washing back into density loop return valve check Density on Flow meter to ensure that the density is close to 1.0.





4. Next turn Density Loop Return Valve to the off position and turn Density Loop Pump off using the start/stop button located near Crystallizer #1.



### Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.

	<b>GILES CHEMICAL ~ PREMIER MAGNESIA</b>		
	<b>Company Procedure</b>		
	Title: <b>Mass Flow Density Loop Washout</b>	Number: <b>P12-PR-200-027</b>	
	Owner: <b>Robert Willis/Lester Parton</b>	Revision: <b>2</b>	
	Effective Date: <b>05/13/13</b>	Page: <b>6 of 7</b>	

5. Return Input valve to the open position to wash back into the crystallizer.





6. Next turn pump on using the start/stop button. Turn Density loop return valve to the open position and then at the same time cut the Input valve on going into the crystallizer and cut off the Density Washout valve to ensure pump will be working properly. Washout is complete.



### Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.

	<b>GILES CHEMICAL ~ PREMIER MAGNESIA</b>	
	<b>Company Procedure</b>	
	Title: <b>Mass Flow Density Loop Washout</b>	Number: <b>P12-PR-200-027</b>
	Owner: <b>Robert Willis/Lester Parton</b>	Revision: <b>2</b>
	Effective Date: <b>05/13/13</b>	Page: <b>7 of 7</b>



## 7.0 Reference Documents

N/A

## 8.0 Change Information

Document review- updated format using new template and numbering system.

### Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.