
	<b>PREMIER MAGNESIA - GILES CHEMICAL</b>			
	<b>COMPANY POLICY</b>			
	<b>Slurry % Retained on 325 Mesh</b>	Page : 1 of 3	Revision : 00 Date : 10/18/2011	
	Author: Lee Cagle	Plant: Waynesville	Area: QC Lab	



**Purpose: Determine % retained on 325 mesh sieve of slurry product**

### Equipment:

325 Mesh Sieve  
 150ml beaker  
 Oven – Baxter Scientific Products  
 Weighing Balance – B440 Satorius  
 Lab Sink  
 Watch Glass Dish  
 High Temp Gloves  
 Sieve Brush

### Procedure:

1. After recording data from slurry sample bottle shake sample until all settling has re-suspended.
2. Turn on oven. ( The dial setting should be at 5 )
3. Place 150ml beaker on balance and tare to zero.
4. Add 100g ( $\pm .04$ g) of slurry sample to beaker.
5. Using the lab sink, start running water through the 325 mesh screen until entire surface is wet.
6. Slowly start pouring the slurry sample through the screen while running water. Continue running water through the screen until no more product will pass through.
7. Shake excess water from the sieve and place in oven. Leave in the oven until sample and sieve have dried.
8. Place glass dish on the balance and tare to zero.
9. Wearing high temp gloves, remove the sieve from the oven and brush dried sample from screen onto the glass dish and record weight in grams. This is your % retained on 325 mesh or % +325.

	<b>PREMIER MAGNESIA - GILES CHEMICAL</b>			
	<b>COMPANY POLICY</b>			
	Slurry % Retained on 325 Mesh	Page : 2 of 3	Revision : 00 Date : 10/18/2011	
	Author: Lee Cagle	Plant: Waynesville	Area: QC Lab	

## TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				



Area: QC Lab

[illegible]