

GILES CHEMICAL									
COMPANY PROCEDURE									
	Palletizer Procedure	Page :	1 of 3	Revision Date	:	02 05/27/09			
Author:	thor: Selwyn Scoggin		ecific						

Personnel responsible:

Lead Operator and / or Salt Operator

Safety equipment:

All safety glasses and appropriate safety apparel is to be worn at all times.

Summary:

The Palletizer and associated conveyors receive the filled bags from the bagger, convey them to the Palletizer where they are arranged into layers and stacked on a pallet. The full pallet is discharged from the Palletizer and conveyed to the stretch wrapper, where it is wrapped and sent to the pick up area.

Procedure:

A. Starting Palletizer

- 1. Inspect Palletizer for loose and/or damaged components.
- 2. Clean up loose bags and salt from conveyors and Palletizer (do not use water).
- 3. Clean all photo eyes with a damp rag.
- 4. Reset safety chord.
- 5. Insure doors on electrical panels for conveyor and Palletizer are closed.
- 6. Press start button on Palletizer.
- 7. Select number of bags per layer and number of layers per pallet.
- 8. Insert adequate number of slip sheets into placer.
- 9. Place no more than 12 pallets into dispenser.
- 10. Reset and start the safety switch at the bagger.
- 11. Press start button on conveyor panel.
- 12. System is now ready to receive bags.

B. Operating Palletizer

- 1. The operator will make rounds as required by the log sheet to observe for proper operation and potential problems.
- 2. Make corrective interventions as required.

C. Stopping Palletizer

- 1. Stop the bagger from sending bags to the Palletizer. Hopefully, the right number of bags to finish a pallet.
- 2. If it is necessary to stop with an uncompleted pallet, press the clear button, and the Palletizer will empty itself.
- 3. Press stop button on Palletizer.
- 4. Insure that all bags, broken and unbroken are removed from conveyors, catwalks, Palletizer, and floor.
- 5. Clean up any residual salt that may have spilled.
- 6. Press stop button on conveyor control panel.



GILES CHEMICAL COMPANY PROCEDURE

Palletizer Procedure

Page : 2 of 3

Revision : Date : 02 05/27/09

Author: Selwyn Scoggin

Job Specific

TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				



GILES CHEMICAL COMPANY PROCEDURE

Palletizer Procedure

Page : 3 of 3

Revision : Date : 05

02 05/27/09

Author: Selwyn Scoggin

Job Specific

Revision Number	Revision Date	Revision Author	Revision Description
00	10/30/05	SS	New Document
01	12/15/06	РО	Updated from Operator Training .
02	05/27/09	JB	Updated to new Company Format
0			