

<b>GILES CHEMICAL CORPORATION</b>		
<b>COMPANY PROCEDURE</b>		
<b>Standard Operating Procedure</b>	Page : 1 of 4	Revision : Date : 3/28/06
Reviewed: Carl Mooney	Title: MEASUREMENT OF PARTICULATE (MgO) EMISSION FROM DIGESTER VENT STACKS	

QA-LAB-19

**Safety:** Observe all area and lab PPE requirements

**Purpose:** MEASUREMENT OF PARTICULATE (MgO) EMISSION FROM DIGESTER VENT STACKS

**Procedure:**

### Introduction

Giles Chemical Corp. operates under an **NCDENR PERMIT TO DISCHARGE** Particulate matter reaching the atmosphere must be limited to      tons per year. . Magnesite (MgO) and salt dust are the only particulates generated by Giles and both are controlled. For regulatory purposes measurements have to be taken from time to time. This procedure allows a close estimation of discharge.of MgO from digester vent stacks

### Procedure.

The digester tanks are both equipped with vent stacks through which particulate magnesite has to pass. A wooden frame has been constructed to which loosely woven (tobacco) cloth can be attached and placed in the discharge stream, thus capturing most of the magnesite being emitted. The exposure time of the cloth to the stream is measured, the cloth folded to retain the particulates, dried, and weighed. The result is calculated in terms of pounds per day.

### Equipment

Loosely woven fabric – cheese or tobacco cloth  
 Wooden Frame  
 Stop Watch  
 Drying Oven – S/P TemoCon NB 6205  
 Weighing Scale – B440 Sartorius

### Method

1. Cut a section of the collection cloth to be used 28" x 28" square.
2. Weight the cloth on the laboratory scale. **Record the weight.**
2. Obtain the wooden frame at its storage location and attach the cloth to the frame securely over the protruding nails.
3. Proceed to the stack to be tested
4. With stop watch at the ready, invert the frame and place it over the vent stack with the nails facing downward.
5. Start the watch immediately. Carefully time the exposure period from the moment of placing the cloth over the stack to the moment of removal.

Timing may have to be adjusted depending upon the amount of dust being emitted and the vapor condensation encountered. A trial run or two may be needed. Generally, the shorter the time the better since excess condensation will induce dripping and introduce error.

GILES CHEMICAL CORPORATION		
COMPANY PROCEDURE		
Standard Operating Procedure	Page : 2 of 4	Revision : Date : 3/28/06
Reviewed: Carl Mooney	Title: MEASUREMENT OF PARTICULATE (MgO) EMISSION FROM DIGESTER VENT STACKS	

QA-LAB-19

6. Allow about two minutes exposure time, then quickly remove and invert the cloth covered frame. **Record the time.**
7. Carefully remove the cloth from the inverted frame, folding the cloth inward to avoid loss of accumulated material.
8. Place the cloth with contents in the drying oven overnight.
9. Weigh the cloth on the laboratory scale. **Record the weight.**
10. Subtract the weight at item 9 from the weight at item 2. **This is the grams of magnesite emitted during the exposure period.**

### Calculation

Determine the grams per minute as above.

Particulate emission for permit purposes is expressed in terms of Tons Per Year.

Grams per ton = 454 (g / pound) x 2000 (lbs./ ton) = 908,000

The operating time of GCC digesters is estimated to be 75% of 7 / 24 per year.

= 0.75 x 60 x 24 x 365 = 394,000

Two digeaters, say 800,000 minutes.

800,000 x g/m divided by 900,000 = tons per year.

<b>GILES CHEMICAL CORPORATION</b>		
<b>COMPANY PROCEDURE</b>		
<b>Standard Operating Procedure</b>	Page : 3 of 4	Revision : Date : 3/28/06
Reviewed: Carl Mooney	Title: MEASUREMENT OF PARTICULATE (MgO) EMISSION FROM DIGESTER VENT STACKS	

QA-LAB-19

### TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				

<b>GILES CHEMICAL CORPORATION</b>		
<b>COMPANY PROCEDURE</b>		
<b>Standard Operating Procedure</b>	Page : 4 of 4	Revision : Date : 3/28/06
	Reviewed: Carl Mooney	Title: MEASUREMENT OF PARTICULATE (MgO) EMISSION FROM DIGESTER VENT STACKS

QA-LAB-19

18				
----	--	--	--	--