

**GILES CHEMICAL ~ PREMIER MAGNESIA****Company Procedure**Title: **USP Crystal LMS Production**Number: **P13-FM-100-020**Owner: **Joe Rogers**Revision: **02**Effective Date: **7/1/15**Page: **1 of 7**

This form is to be used when producing a load of high-grade LMS from dissolved USP Crystal.

LMS Lot #: _____ **Start Date:** _____ **Start Time:** _____

Material	Weight %	Target	Actual	Lot Number
USP Magnesium Sulfate	55.3 (hepta basis)	26000 pounds		
City Water	44.7	2518 gallons		n/a
Total	100.0	47000 pounds		See above

Pre-production Cleaning

- | | Initials | Time |
|--|----------|-------|
| 1. Ensure that the Holding Tank is clean, empty, and dry. | _____ | _____ |
| 2. Ensure Dissolving Tank is empty | _____ | _____ |
| 3. Rinse the Dissolving Tank with City Water | _____ | _____ |
| 4. Close bottom valve and fill with City Water | _____ | _____ |
| 5. Turn on steam coils and condensate return | _____ | _____ |
| 6. Ensure 3-Way Transfer valve is in the "down position" | _____ | _____ |
| 7. Open Circulation valve, turn on the Circulation pump, and circulate water for 30 minutes or until the water temperature reaches 74 C or higher. Temp: _____ | _____ | _____ |
| 8. Stop Circulation and Drain the tank by opening the bottom valve | _____ | _____ |
| 9. Repeat steps 3 through 7 again to ensure tank is clean. | _____ | _____ |
| 10. Get a second person to verify tank is clean before continuing. | _____ | _____ |
| 2 nd person: | _____ | _____ |

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.



GILES CHEMICAL ~ PREMIER MAGNESIA

Company Procedure

Title: USP Crystal LMS Production

Number: P13-FM-100-020

Owner: Joe Rogers

Revision: 02

Effective Date: 7/1/15

Page: 2 of 7



Dissolving USP Crystal

BATCH 1

Initials Date

1. Close bottom valve and using the flow meter, add 581 gallons of water to the dissolving tank.

2. Ensuring 3-way valve is in the down position and steam coils are on, start the circulation pump.

3. Allow the water temperature to reach 74C or higher

4. Add 3 (THREE) tons of USP Crystal, noting the lot number of the salt added as Batch 1

5. Check the sacks off on the "Sack Check" AFTER they have been put into the tank.

6. Allow the solution to reach 74 C or higher.

7. Ensure piping on the 3-way Transfer Valve is set up to transfer the LMS to the Hold Tank.

8. Place the 3-way Transfer Valve into the "up position" to transfer the LMS to the hold tank.

<u>Product</u>	<u>Date</u>	<u>Lot number</u>

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.

**GILES CHEMICAL ~ PREMIER MAGNESIA****Company Procedure**Title: **USP Crystal LMS Production**Number: **P13-FM-100-020**Owner: **Joe Rogers**Revision: **02**Effective Date: **7/1/15**Page: **3 of 7****BATCH 2****Initials Date**

1. Once the transfer is complete, place the 3-way Transfer Valve in the “down position” and using the flow meter, add 581 gallons of water to the Dissolving Tank.

2. Allow the water temperature to reach 74C or higher

3. Add 3 (THREE) tons of USP Crystal, noting the lot number of the salt added as Batch 2

4. Allow the solution to reach 74 C or higher.

5. Ensure piping on the 3-way Transfer Valve is set up to transfer the LMS to the Hold Tank.

6. Place the 3-way Transfer Valve into the “up position” to transfer the LMS to the hold tank.

<u>Product</u>	<u>Date</u>	<u>Lot number</u>

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.



GILES CHEMICAL ~ PREMIER MAGNESIA

Company Procedure

Title: USP Crystal LMS Production

Number: P13-FM-100-020

Owner: Joe Rogers

Revision: 02

Effective Date: 7/1/15

Page: 4 of 7



BATCH 3

Initials Date

1. Once the transfer is complete, place the 3-way Transfer Valve in the “down position” and using the flow meter, add 581 gallons of water to the Dissolving Tank.

2. Allow the water temperature to reach 74C or higher

3. Add 3 (THREE) tons of USP Crystal, noting the lot number of the salt added as Batch 3

4. Allow the solution to reach 74 C or higher.

5. Ensure piping on the 3-way Transfer Valve is set up to transfer the LMS to the Hold Tank.

6. Place the 3-way Transfer Valve into the “up position” to transfer the LMS to the hold tank.

<u>Product</u>	<u>Date</u>	<u>Lot number</u>

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.

**GILES CHEMICAL ~ PREMIER MAGNESIA****Company Procedure**Title: **USP Crystal LMS Production**Number: **P13-FM-100-020**Owner: **Joe Rogers**Revision: **02**Effective Date: **7/1/15**Page: **5 of 7****BATCH 4**

1. Once the transfer is complete, place the 3-way Transfer Valve in the “down position” and using the flow meter, add 581 gallons of water to the Dissolving Tank.

Initials Date

2. Allow the water temperature to reach 74C or higher

3. Add 3 (THREE) tons of USP Crystal, noting the lot number of the salt added as Batch 4

4. Allow the solution to reach 74 C or higher.

5. Ensure piping on the 3-way Transfer Valve is set up to transfer the LMS to the Hold Tank.

6. Place the 3-way Transfer Valve into the “up position” to transfer the LMS to the hold tank.

<u>Product</u>	<u>Date</u>	<u>Lot number</u>

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.

**GILES CHEMICAL ~ PREMIER MAGNESIA****Company Procedure**Title: **USP Crystal LMS Production**Number: **P13-FM-100-020**Owner: **Joe Rogers**Revision: **02**Effective Date: **7/1/15**Page: **6 of 7****BATCH 5****Initials Date**

1. Once the transfer is complete, place the 3-way Transfer Valve in the “down position” and using the flow meter, add 581 gallons of water to the Dissolving Tank. _____
2. Allow the water temperature to reach 74C or higher _____
3. Add 3 (THREE) tons of USP Crystal, noting the lot number of the salt added as Batch 5 _____
4. Allow the solution to reach 74 C or higher. _____
5. Ensure piping on the 3-way Transfer Valve is set up to transfer the LMS to the Hold Tank. _____
6. Place the 3-way Transfer Valve into the “up position” to transfer the LMS to the hold tank. _____

<u>Product</u>	<u>Date</u>	<u>Lot number</u>

Load is Complete**Initials Date**

1. Once the transfer is complete, stop the pump, open the bottom valve, and wash out the tank with city water. _____
2. Close the valve on the Holding Tank and rinse the piping with City Water. _____
3. Close the steam valve and the condensate valve on steam coils _____

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.



GILES CHEMICAL ~ PREMIER MAGNESIA

Company Procedure

Title: **USP Crystal LMS Production**

Number: **P13-FM-100-020**

Owner: **Joe Rogers**

Revision: **02**

Effective Date: **7/1/15**

Page: **7 of 7**



- Note the total amount of water, salt, and the salt lot number on the table at the top of this batch sheet. _____

Holding Tank and Quality Check

Initials Date

- Circulate the holding tank for 45 minutes. Time Started: _____ Time Finished: _____

- Sample the Holding Tank into a clean Nalgene sample bottle, label with date, time, Lot number, and operator initials.

- Take sample to the Quality Lab for testing.

- Once the sample is approved by Quality, have them initial the approval on this batch sheet:

Quality Disposition (approved or rejected): _____

Approved by: _____

Date and Time _____

Loading

- Once the batch is approved by Quality, the batch can be loaded onto the tanker.
- Use "Liquid Loading System" procedure, P13-PR-200-072, to load the truck. Consider the Holding Tank as the Brine Tank for this purpose. _____
- When load is complete, rinse the holding tank with city water and leave drain valve open. _____

Manager Approval / Verification:

Signature: _____ Date: _____

Manager – Attach Liquid Loading System print out and send batch sheet to Quality for filing.

1.0 Reference Documents

N/A

2.0 Change Information

Change to new Doc System Format.

Controlled Document

Only those quality documents viewed through the Giles Chemical electronic Documentation System are officially controlled. All other copies, whether viewed through another computer program or a printed version, are not controlled and, therefore, the Quality Unit at Giles assumes no responsibility for the accuracy of the document.