

GILES CHEMICAL									
COMPANY PROCEDURE									
	Dryer Procedure	Page	:	1 of 3	Revision Date	:	02 05/27/09		
Author:	Selwyn Scoggin / Patrick Owen	Job S	Spe	ecific					

**Personnel responsible:** 

Lead Operator and / or Salt Operator

#### **Safety equipment:**

All safety glasses and appropriate safety apparel is to be worn at all times.

#### **Summary:**

The dryers take the damp salt from the centrifuge and dry the surface moisture so the salt can be stored in a bag or super sack for an extended period of time without sticking.

#### **Procedure:**

### A. Starting dryers:

- 1. Start dryer rotation by pressing dryer start buttons on MCC #2, and then pressing the start buttons on the Variable Speed Drives for the dryers.
- 2. Start the dryer dust collector fans. The Switches are at the back near each dust collector.
- 3. Start the dryer intake fans. The switches are at the back near the water recovery room.
- 4. Open steam control valve isolators, main steam valves and condensate valves to the heaters.
- 5. At the Monitoring System display, set the exit air temperature controls to 45 C.
- 6. Allow dryers to warm up for 30 min.
- 7. Blow down the condensate out of the radiators by opening the condensate blow down valve for approximately 10 seconds on each dryer.
- 8. Confirm dryer temperature controls are adjusted properly.
- 9. Begin feed to the dryers and adjust temperature controls accordingly.

#### B. Normal operation:

- 1. Operators are to continually monitor the dryer operation and record the operating parameters.
- 2. The salt temperature range will be posted on the Doc System Manufacturing Screen.
- 3. Examine the condition of the salt and make adjustments as required.

#### C. Shutting down dryers:

- 1. Stop crystal feed to the dryers.
- 2. Allow all salt in dryers to empty out into the discharge screw.
- 3. Press Stop on the Variable Speed Drives.
- 4. Shut off steam and condensate valves to heaters.
- 5. Stop dryer inlet fans.
- 6. Stop dryer dust collector fans.



# GILES CHEMICAL COMPANY PROCEDURE

Dryer Procedure Page : 2 of 3

Job Specific

Revision Date 02 05/27/09

Author: Selwyn Scoggin / Patrick Owen

### TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				



Author:

# GILES CHEMICAL COMPANY PROCEDURE

Revision Date 02 05/27/09

Dryer Procedure Page: 3 of 3

Selwyn Scoggin / Patrick Owen Job Specific

Revision Number	Revision Date	Revision Author	Revision Description
00	10/30/05	SS	New Document
01	06/11/08	РО	Changed MCC#1 to #2 On step 1.
02	05/27/09	JB	Updated to new Company Format