

	GILES CHEMICAL		
	COMPANY PROCEDURE		
	Monthly Critical Parameter Verification	Page : 1 of 4	Revision : 00 Date : 11/2/2010
	Author: Patrick Owen		Job Specific

Date Performed: _____ **Next Due Date:** _____

Personnel responsible:

1. Process Engineer

Safety:

Safety shoes and safety glasses are required when working in the plant.

Procedure:

1. Brine Transfer Flow-

Check the flow with the hand held external flow meter. The minimum acceptable flow is 60 gpm.

Measured flow: _____

If the flow is below 60 gpm, the line needs to be pressure washed and remeasured.

Comments: _____

2. Crystallizer Mother Liquor Flow

The Mother Liquor flow meter for the Crystallizers is checked with the external flow meter. The flow meters should agree within 5%. If not, clean the Mother Liquor meter and check the readings again.

#1 Handheld flow: _____ gpm #1 Meter flow: _____ gpm % Difference _____

#2 Handheld flow: _____ gpm #2 Meter flow: _____ gpm % Difference _____

#3 Handheld flow: _____ gpm #3 Meter flow: _____ gpm % Difference _____

Comments: _____

3. Crystallizer Brine Flow

The Brine feed flow meter for the Crystallizers is checked with the external flow meter. The flow meters should agree within 5%. If not, clean the flow meter and check the readings again.

#1 Handheld flow: _____ gpm #1 Meter flow: _____ gpm % Difference _____

#2 Handheld flow: _____ gpm #2 Meter flow: _____ gpm % Difference _____

#3 Handheld flow: _____ gpm #3 Meter flow: _____ gpm % Difference _____

Comments: _____



GILES CHEMICAL
COMPANY PROCEDURE

Monthly Critical Parameter Verification

Page : 2 of 4

Revision : 00
Date : 11/2/2010

Author: Patrick Owen

Job Specific

4. Crystallizer Discharge Flow

The discharge flow meter for the Crystallizers is checked with the external flow meter. The flow meters should agree within 5%. If not, clean the discharge flow meter and check the readings again.

#1 Handheld flow: _____ gpm #1 Meter flow: _____ gpm % Difference _____

#2 Handheld flow: _____ gpm #2 Meter flow: _____ gpm % Difference _____

#3 Handheld flow: _____ gpm #3 Meter flow: _____ gpm % Difference _____

Comments: _____

5. Crystallizer Vacuum

The vacuum for the Crystallizers is checked with an external gauge. The gauge should agree within 0.1" Hg. If not, wash the Crystallizer instrument with hot water and record the readings again.

#1 Gauge Vacuum: _____ "Hg #1 Monitor Vacuum: _____ "Hg Difference _____

#2 Gauge Vacuum: _____ "Hg #2 Monitor Vacuum: _____ "Hg Difference _____

#3 Gauge Vacuum: _____ "Hg #3 Monitor Vacuum: _____ "Hg Difference _____

Comments: _____

6. Crystallizer Temperature

The temperature for the Crystallizers is checked with a thermometer. Take a sample from the density loop and measure the temperature with a thermometer. The thermometer and Monitoring System readout should agree within 1C. If not the Monitoring System reading will need to be adjusted.

#1 Thermometer: _____ C #1 Monitor Temp: _____ C Difference _____

#2 Thermometer: _____ C #2 Monitor Temp: _____ C Difference _____

#3 Thermometer: _____ C #3 Monitor Temp: _____ C Difference _____

Comments: _____



**GILES CHEMICAL
COMPANY PROCEDURE**

Monthly Critical Parameter Verification

Page : 3 of 4

Revision : 00
Date : 11/2/2010

Author: **Patrick Owen**

Job Specific

TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				

