

GILES CHEMICAL CORPORATION							
COMPANY PROCEDURE							
	Air compressor-weekly pm	Page	:	1 of 2	Revision Date	:	1 06/18/07
Author:	Randy Lanning	Repor	t #:				

Safety: Follow all area safety rules. Wear the appropriate PPE when working.

**Purpose:** The purpose of this procedure is to describe the maintenance requirements for the air compressor on a weekly schedule.

## WEEKLY CLEANING OF THE AIR COMPRESSOR (PM)

- 1. Check air intake filter-inside cabinet; replace if required
- 2. Check oil level; fill to appropriate level if needed
- 3. Clean radiator filter with water
- 4. Blow out radiator with compressed air to remove all dust accumulation



GILES CHEMICAL CORPORATION							
COMPANY PROCEDURE							
	Air compressor-weekly pm	Page	:	2 of 2	Revision Date	:	1 06/18/07
Author:	Randy Lanning	Repor	t #:				

## TRAINING DOCUMENTATION

EMPLOYEE	TITLE	SIGNATURE	DATE
1			
2			
3	Augustian August		
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			