

GILES CHEMICAL CORPORATION		
COMPANY PROCEDURE		
Standard Operating Procedure	Page : 1 of 3	Revision : 12/15/2005 Date : 10/28/2005
Author: Patrick Owen	Title: (00)Cleaning the MgO Mix Pot	

Manuf- MgO-01

### Personnel responsible:

1. Lead Operator, Material Handler

### Safety:

Safety shoes and safety glasses are required when working in, on, or around the digesters.

Do not place your hands under the surface of the liquid in the mix pot with the agitator plugged in – the agitator blades can cut your fingers off!

### Summary:

The mix pots are a critical piece of equipment. Their correct operation ensures that the MgO is fed to the digester in such a way that the MgO neither leaves through the Digester vent, nor clumps together and forms oxysulfate cement that sinks to the bottom. If a mix pot is in use, it should be cleaned once a shift. The feed chute should be cleaned and knocked every time the digester is checked.

### Procedure:

1. Turn the MgO Drive off; On Side #2 also turn off the Long MgO Screw and the Short MgO Screw.
2. Unplug the Mix Pot agitator.
3. Open the cover on the mix pot.
4. Use the scraper tool to knock the chute and scrape the chute clean.
5. Wipe or wash the excess MgO from all surfaces, using the hose if needed.
6. Be careful to use as little water as possible, so the density doesn't fall.
7. Ensure the drain to the digester is not clogged. If it is clogged, rod and or pressure wash it to open it up.
8. Plug in the agitator.
9. Turn on the MgO Drive; on side #2 also turn on the Long MgO Screw and the Short MgO Screw.
10. Make sure the MgO is flowing properly.
11. Close the lid on the MgO Pot.

<b>GILES CHEMICAL CORPORATION</b>			
<b>COMPANY PROCEDURE</b>			
<b>Standard Operating Procedure</b>		Page : 2 of 3	Revision : 12/15/2005 Date : 10/28/2005
Author:	Patrick Owen	Title: (00)Cleaning the MgO Mix Pot	

Manuf- MgO-01

**TRAINING DOCUMENTATION**

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				

<b>GILES CHEMICAL CORPORATION</b>		
<b>COMPANY PROCEDURE</b>		
<b>Standard Operating Procedure</b>	Page : 3 of 3	Revision : 12/15/2005 Date : 10/28/2005
Author: Patrick Owen	Title: (00)Cleaning the MgO Mix Pot	

Manuf- MgO-01

### **REVISION HISTORY**

<u>Revision Date</u>	<u>Revision Number</u>	<u>Revision Description</u>
11/28/05	00	New Document
12/15/05	01	Updated after training